



KBR-3D RF Shielding Tech Bulletin 1-2005

The provided metal tape with adhesive when applied as shown will block certain interference from cell and portable phones from entering the tube and creating noise through the amplifier.

1. Remove chassis as per owners manual, if you do not have one, download from www.motion-sound.com support area.
2. Remove tube retainer (on some models) and any shielding from the tube.
3. If there is a ground wire from the PC board to the tube shielding, cut the wire from the PS board.
4. Remove the backing from the tape *ONLY* in areas where it sticks to the chassis, leave the paper on the rest of the tape for insulation purposes.
5. Carefully bend and apply the tape as shown, do not allow the metal tape to contact the PC board.
6. Re-assemble as per owners manual.



